


About using Windows 8.1 / Server 2012 R2

When you use this driver and software in Windows 8.1 / Server 2012 R2, please refer to the instruction of Windows 8 or Server 2012 described in each software guide.

There is a procedure different from this operation. Please operate it according to the following.

- **Displaying list of Apps (All Programs)**

Procedure
(1) Move the mouse cursor in the Start screen, and click  .

- **Starting up the software**

Procedure
(1) Click the software tile in the Apps view.

< About using by OS upgrade >

This driver and software do not support use by OS upgrade.

Please uninstall the installed driver and software before OS upgrades, and install them again after OS upgrades.

Please operate the following when you upgrade OS without uninstalling them.

- 1) Uninstall the driver software.
- 2) Install it again.
- 3) Reboot the OS.

* Please refer to installation guide for uninstallation and the installation method.